








**Solid Plastic Top Walk-  
Thru ADA Table  
Instructions BM1460**

REV # 1  
6/7/2017



# Solid Plastic Top Walk-Thru ADA Table Instructions BM1460




## REQUIRED TOOLS (NOT INCLUDED)

- 1 - 1/2" WRENCH
- 1 - 1/2" SOCKET


**HARDWARE &  
TOOLS REQUIRED  
FOR ASSEMBLY**

**2/7**


# Solid Plastic Top Walk-Thru ADA Table Instructions BM1460




**70**  
5/16" WASHER  
WUSS031WAS188




**3**  
5/16" NUT  
NFHX031CNUT188



**1**  
5/16-18 X 1" HEX BOLT  
HHCS031C100188



**2**  
5/16-18" X 3" CARRIAGE BOLT  
CARR031C300188




**66**  
5/16" X 1.25" LAG SCREW  
HLAG031C125188

# Solid Plastic Top Walk-Thru ADA Table Instructions BM1460


## STEP #1 Tabletop Assembly

- Lay three boards (D) on a flat clean surface with alignment marks visible
- Lay table top support (A) on 3 boards (D) aligning holes with the alignment marks
- Secure lag screws (K) thru washers (G) thru table top support (A) into plastic boards (D)



## STEP #2 Seat Assembly



- Lay one board (E) top side down on a flat clean surface
- Lay seat support (B) on board (E) aligning holes with the flat side down
- Secure lag screws (K) thru washers (G) thru table top support (A) into plastic board (E)
- Repeat for remaining board (E) and seat support (B)



# Solid Plastic Top Walk- Thru ADA Table Instructions **BM1460**



## STEP #3 Installing Plastic End Supports

- Stand plastic end supports (F) upright, 50.0" apart
- Set assembled top from Step #1 on top of plastic ends (F)
- Attach top assembly to plastic ends (F) with lag screws (K) thru washers (G) thru table top support (A) into plastic ends (F) making sure ends are at 90 degrees




## STEP #4 Installing angle support braces

- Place a 5/16" x 1" hex bolt (I) thru washer (G) the two angle support braces (C) and table top support (A) and hand tighten with a nut (H) See DETAIL 1
- Attach the angle support braces (C) to the plastic ends (F) with 5/16" x 3" carriage bolts (J) thru plastic ends (F) thru angle support (C) thru washer (G) to nut (H) See DETAIL 2
- Tighten all nuts and bolts



Angle support brace  
connection to  
plastic end support






Angle support brace  
connection to  
center channel

# Solid Plastic Top Walk-Thru ADA Table Instructions BM1460

## STEP #5 Installing Seats

- Set assembled seats from Step #2 on top of plastic ends (F)
- Attach seat assembly to plastic ends (F) with lag screws (K) thru washers (G) thru seat support (B) into plastic ends (F)
- Repeat for other seat







**INSTALLING  
SEATS**

**6/7**

# Solid Plastic Top Walk-Thru ADA Table Specifications BM1460

REV # 1  
6/7/2017



ALL DIMENSIONS ARE SHOWN IN INCHES