


BENCH INSTRUCTIONS BC1060 - BC1065


STEP 1 Seat Assembly

- Locate the seat assembly (A) and place upside down on a clean level surface
- Align the predrilled holes in the bench legs (B) with the predrilled holes in the seat assembly (A)
- Insert (1) 3/8" x 3.5" hex bolt (D) with a 3/8" flat washer (G) into each center hole in seat assembly (A) and bench leg (B)
- Secure each bench leg (B) with a 3/8" flat washer (G) and 3/8" hex nut (F)
- Repeat for each bench leg (B)



STEP 2 Seat Assembly

- Align the two outer holes in the bench legs (B) with the corresponding holes in the base of the seat assembly (A)
- Drive (2)'1/4" x 2.5" lag screws (C) with 1/4" flat washers • (E) through the face of the bench leas (B) and into the base of the seat assembly
- •
- Repeat for each bench leg (B) Square all parts and tighten all hardware ٠



BENCH INSTRUCTIONS BC1060 - BC1065

- STEP 3 Inground Mount
 Dig three holes 18.5 inches deep by 12 inches in diameter
 Place assembled bench into holes
- Check seat height. Seat should be about 17 inches from the ground Check to see that seat and posts are level and square Fill the holes with concrete ٠
- ٠
- ٠

Note: You may have to attach guide wires or some other form of support to keep the bench level until the concrete hardens.

